

'Piranha Off Road products are not associated in any way with Toyota Australia or any of its related companies'

To Suit LANDCRUISER 80 SERIES 3F PETROL (Carby)



PART NUMBER	BT80PO
APPROX FITTING TIME	1 Hours
MAX BATTERY SIZE	300mm L
MAX BATT WEIGHT	23Kg
CYCLE DUTY	
TRAY LOCATION	PSF



PARTS INCLUDED WITH TRAY

- 1 X Tray
- 1 X M6 Bolt (Countersunk)
- 1 X M6 Hex Bolt
- 1 X M6 Nut
- 1 X M6 Body Washer
- 2 X M8 Bolt Long
- 1 X Universal Top Mount
- 2 X J Bolts

RECOMMENDED ISOLATOR

DBE140SF
or
DBE180-SX

FITTING INSTRUCTIONS

The cradle fits passenger side front.

This tray can be used as an OEM replacement tray for the starting battery in some versions of the 80 series

The tray arm bolts to the inner fender using a 6mm bolt and the 2 x lower mounts bolt to existing threaded holes using 8mm bolts.

Once bolts are tight, drill the hole in the corner of the tray closest to the washer bottle. Secure with 6mm countersunk bolt and nut with a body washer on the underside of the guard.

Ensure, before closing the bonnet that all items fitted have adequate clearance