Piranha Off Road products are not associated in any way with FORD Motor Co of Aust Ltd or any of its related companies'

To Suit F100 / F150 / BRONCO V8 PETROL (with plastic inner guard)





NOT SUITABLE For self fit

FOR



PARTS INCLUDED WITH TRAY

- 2 X M6 Nuts
- 2 X M6 Weldbolts
- 1 X M8 Bolt Short
- 1 X M8 Nut
- 2 X J Bolts
- 1 X Universal Top Mount

FITTING INSTRUCTIONS

The cradle fits passenger side rear.

With plastic mud guard it looks flimsy however, it is strong. The battery sits slightly on an angle, this is correct. Fitting is not simple as body washers are required.

RECOMMENDED ISOLATOR

DBE140SF or DBE180-SX Ensure, Before closing the bonnet that all items fitted have adequate clearance

Nov 2017