

'Piranha Off Road products are not associated in any way with FORD Motor Co of Aust Ltd or any of its related companies'

## To Suit PXFORD RANGER 2011 - 2015 with NO TUB LINER



PART NUMBER	BTMFR
APPROX FITTING TIME	1 Hour
MAX BATTERY SIZE	300mm 32Kg
RECOMMENDED TYPE	SEALED AGM
TRAY LOCATION	TUB



### PARTS INCLUDED WITH TRAY

- 1 X Special Top Mount
- 2 X Spacers 8mm
- 2 X M6 30mm
- 2 X M6 50mm
- 1 X M6 15mm
- 2 X M6 Countersunk 25mm
- 6 X M6 Nuts
- 2 X Washers
- 1 X 4 Hole Support Plate
- 1 X 2 Hole Support Plate
- 1 X Top Mount Support BKT  
TM RANGER
- 2 X J Bolts
- 1 X Top Mount

### RECOMMENDED ISOLATOR

**DBE140SF / DBE180-SX**  
Have Dealer Turn OFF  
Smart Charge Feature

1. Place tray in position
2. Drill 4 X 6mm holes through plate into wheel arch
3. Bolt tray to side of wheel arch with 2X M6 30mm on lower and 2X M6 50mm on upper placing 2 X spacers between plate and body .Check inner guard for bolt protrusion.
4. Drill 2 X 6mm holes through base of tray through top of wheel arch.
5. Bolt tray to top of wheel arch using support plate under guard with washers with 2 X M6 countersunk 25mm
6. Place battery in position secure with J bolts and top mount and top mount support bracket to go between top mount and side rail, secure with 1 X M6 15mm.

**ENSURE POSITIVE TERMINAL IS ADEQUATELY COVERED TO PREVENT SHORTING**