PIRANHA OFFROAD PRODUCTS

DISGVO

'Piranha Off Road products are not associated in any way with SUZUKI Australia Pty Ltd or any of its related companies'

To Suit SUZUKI GRAND VITARA V6 PETROL















PARTS INCLUDED WITH TRAY

- 1 X Tray
- 6 X M6 Nuts
- 3 X M6 Bolts Hex
- 1 X M6 Bolt Countersunk
- 1 X M6 Bolt Long
- 2 X M6 Weld Bolts
- 1 X M6 Washer
- 1 X Backing Plate
- 2 X J Bolts
- 1 X Special Top Mount
- 1 X 600mm Hose

RECOMMENDED ISOLATOR

DBE140SF or DBE180-SX

FITTING INSTRUCTIONS

The cradle fits passenger side front.

- 1. Remove overflow bottle and drill out four spot welds in guard.
- 2. Remove bracket
- 3. Place in battery tray counter sunk in tray aligns with captive in inner guard
- 4. Rear bottom brace aligns to captive in guard. A long M6 must be threaded through from under guard then brace is bolted to this with M6 nut
- 5. Front brace on inner guard needs to be marked & drilled (Tray may need to come out once marked)
- 6. Place tray back in bolt in rear bolts as described in points 3 & 4, then use M6 hex, nut & washer to bolt in front brace (engine side)
- 7. Two M6 hex bolt down last support using two M6 nuts & backing plate
- 8. Cut overflow bottle bracket then bolt to side of tray using two weld bolts & M6 nuts
- 9.Place battery in tray, squeeze top mount between guard & inner guard. Drill hole & bolt
- 10. Replace overflow bottle hose with longer hose

Nov 2017